

# Flotec®

FP7KV

FP14KVX

VIPVORT 130/5

VIPVORT 180/6



CE



<b>I</b> Manuale di uso e manutenzione	pag. 1	<b>N</b> Instruksjonshåndbok og vedlikehold	pag.37
<b>GB</b> Use and maintenance manual	" 5	<b>SE</b> Bruks och underhålls anvisningar	" 41
<b>F</b> Manuel d'utilisation et d'entretien	" 9	<b>GR</b> ΕΓΧΕΙΡΙΔΙΟ ΧΡΗΣΗΣ ΚΛΙ ΕΥΝΤΡΗΡΗΣ	" 45
<b>D</b> Bedienungs- und Wartungsanleitung	" 13	<b>PL</b> Reczynny uzywane i obslugi	" 49
<b>E</b> Manual de uso y manutención	" 17	<b>RO</b> Manual de folosire intretinere	" 53
<b>P</b> Manual de utilização e manutenção	" 21	<b>H</b> Hanznàloti utasitàs karbantartás	" 57
<b>NL</b> Handleiding voor gebruik en onderhoud	" 25	<b>CZ</b> Nàvod k pouziti a k údržbe	" 61
<b>DK</b> Vejledning til brug og vedligeholdelse	" 29	<b>TR</b> Kullanma ve bakım el kitabı	" 65
<b>FIN</b> Käyttö ja kunnssapito	" 33	<b>RUS</b> Инструкци по установке и функционированиё	" 69

Dear client,

Congratulations on your purchase of this FLOTEC product. Like all FLOTEC products, it has been developed with the help of the latest technologies and manufactured with the most advanced electrical/electronic parts.

Take the time to read the instructions carefully before using this appliance.

Thank you!

## Contents

Ch. 1	Features .....	GB 1
Ch. 2	Limitations .....	GB 1
Ch. 3	Installation .....	GB 2
Ch. 4	Electric Connection - Start-up .....	GB 3
Ch. 5	Maintenance and troubleshooting .....	GB 3
Appendix	Figures .....	pg. 73

Warnings for the safety of individuals and objects.

Carefully follow the instructions marked with the following symbols.



DANGER

Keep the technical equipment out of the reach of children!



DANGER  
Electric shock  
risk

Warns that the failure to follow the directions given may cause electric shock.



DANGER

Warns that the failure to follow the directions given could cause serious risk to individuals or objects.



WARNING

This sign warns the operator that the failure to follow an instruction may damage the pump and/or the system.

## Ch. 1 Features

WARNING: Read this manual carefully before installing this pump.

This sign warns the operator that the failure to follow an instruction may damage the pump and/or the system.

Carefully store this manual. If problems arise, contact the Customer Assistance Service. Please verify that the pump has been used correctly and that the cause of the problem is not imputable to its operation.

Every electropump is carefully tested and packed during its assembly.

On receiving the pump, check that the pump has not been damaged during transportation. If the pump is damaged, immediately inform the dealer within 8 days from the date of purchase.

## Ch. 2 Limitations

FLOTEC VIPVORT, FP14 KVX, FP7 KV series electropumps are suitable to pump dirty water containing suspended solid particles. These pumps can be used both for permanent and temporary installations and in particular to empty collection basins containing dirty or waste waters.



WARNING

The pump cannot be used for sea water and inflammable, corrosive, explosive or dangerous liquids.



WARNING

Verify that the electropump never runs without liquids.

Technical Data	VIPVORT 130/5	VIPVORT 180/6	FP14KVX	FP7KV
Mains voltage / frequency	230 V ~ 50 Hz	230 V ~ 50 Hz	230 V ~ 50 Hz	230 V ~ 50 Hz
Absorbed power	370 Watt	480 Watt	600 Watt	350 Watt
Type of protection / Insulation class	IP 68 / F	IP 68 / F	IPX8 / B	IP68 / F
Suction fitting	41,90 mm (1"1/4 M)	41,90 mm (1"1/4 M)	41,90mm(1"1/4M)	41,90mm(1"1/4M)
Maximum flow rate	7.800 l/h	10.800 l/h	14.000 l/h	7.800 l/h
Maximum head	5 m	6 m	8 m	5 m
Maximum depth of immersion	7 m	7 m	5 m	7 m
Power cable	10 m H05 RNF	10 m H07 RN8-F	10 m H05 RNF	10 m H05 RNF
Weight	3,9 Kg	4,2 Kg	5 Kg	2,9 Kg
Maximum dimension of pumped solid particles	25 mm	25 mm	22 mm	25 mm
Maximum temperature of the pumped fluid	35° C	35° C	35° C	35° C
Maximum number of starts per hour	30	30	30	30
Minimum priming level (A)*	150 mm	150 mm	94 mm	150 mm
Minimum suction level (B)*	30 mm	30 mm	37 mm	30 mm
Connection level (C)*	330 mm	330 mm	370 mm	330 mm
Stop level (D)*	150 mm	150 mm	190 mm	150 mm

Sound pressure level (L<sub>pa</sub>) equal to or less than 70 dB(A)

Sound emission values obtained in conformity with the EN 12639 standard

[\*] These data refer to Fig. 1. Measurements are expressed in millimetres.

The minimum priming level corresponds to a condition in which the delivery mouth is completely submersed.

(See Fig. 1 - Reference A)

The pumps of this series are not suitable for table fountains or aquariums. If these pumps are used in continuous mode for ponds with fish, it is necessary to check them at regular intervals of 6 months (if the water contains aggressive substances). It is also advisable to check the maximum dimension of particles recommended for the pump and take the necessary measures to prevent the fish from being sucked into the pump.

### Ch. 3 Installation (see Fig. 1)



**DANGER**  
Electric shock  
risk

When installing, please ensure electropump is disconnected from electrical supply. Pumps in this series are not suitable for use in a swimming pool and the relevant cleaning and servicing operations.



**DANGER**

To prevent possible injuries to people, avoid inserting hands into the mouth of the pump if this is connected to the mains.



**DANGER**

This appliance can be used by children aged 8 years or over and by persons with limited physical, sensory or intellectual capabilities, or with limited experience and knowledge, provided that they are supervised or have been instructed in the safe use of the appliance and are aware of the dangers involved. Children must not be allowed to play with the appliance. Cleaning and user maintenance must not be carried out by children unless they are supervised



**WARNING**

Pollution of the liquid could occur due to the leakage of lubricants

Use the handle provided to transport or lift the pump.

To use the pump in permanent installations with rigid pipes, to install a check valve to avoid the fluid being re-circulated once the pump is stopped. The installation of a quick closing fitting in a convenient position facilitates cleaning and maintenance operations.

The dimensions of the collection container should reduce to the minimum the number of starts per hour (see LIMITATIONS - Technical data).

To use the pump for temporary applications, install a flexible pipe and connect it to the pump using a pipe holder. To immerse the pump, use a rope and fix it to the handle.

FLOTEC VIPVORT, FP14 KVX, FP7 KV pumps have a pre-set floating switch. To change the setting, it is necessary to increase or reduce the length of the floating switch cable by sliding it in the slot on the handle (See Fig. 1).



**WARNING**

Verify that the floating switch stops the pump as soon as the minimum level is reached.



**WARNING**

Make sure that the floating switch is free to move.

(see also Fig. 7 and 8)

The pumps used in ponds, small lakes, fountains or similar installations or close to them should have a cut-out switch. Contact a specialised electrician.

### Pump anchorage

Use the slots on the filter cap [see Fig. 2, pos. 1] to anchor the pump. Then, remove the inserts from the filter cap. It is also possible to insert 3 screws in the widest section of the slots [see Fig. 2, pos. 2] and turn the filter cap counterclockwise so that the screws keep the cap in place in the narrowest section of the slots [Fig. 2, pos. 3]. After fixing the filter cap, it is necessary to insert the pump in the related guides [see Fig. 3, pos. 4] and turn it counterclockwise to fix it in place [Fig. 5].

## Ch. 4 Electric Connection - Start-up



WARNING

Verify that the voltage and frequency of the electropump shown on the nameplate correspond to those available on the mains.



DANGER  
Electric shock  
risk

The installer must make sure that the electric system is grounded in accordance with the law in force.



DANGER  
Electric shock  
risk

Make sure that the electric system has a high-sensitivity circuit breaker  $D = 30$  mA (DIN VDE 0100T739).

### Instructions for a safe pump start

The power cable should have a minimum section equivalent to that of H05 RN-F. To be able to use the pump outdoors, it is necessary to use cable with a length of 10 m. The plug and connections should be protected by water splashes.

Before using the pump, always inspect it visually (especially power cable and plug). Do not use the pump if it is damaged. If the pump is damaged, have it inspected by the specialised assistance service only.

Make sure that electric connections are protected from inundation.

Protect the plug and the power cable from heat, oil or sharp edges.



DANGER  
Electric shock  
risk

The power cable must be replaced by qualified personnel only.

### Grounding

The plug of the power cable has a double grounding contact, so that grounding can be performed by simply inserting the plug.

### Overload protection

FLOTEC VIPVORT series pumps have a built-in thermal protection switch. The pump stops if an overload condition occurs. The motor restarts automatically after it has cooled down (see point 4 of the Troubleshooting section for information on causes and corrective actions).

To start the pump, insert the plug in a 230 V alternate current socket.

ATTENTION: the pump runs as soon as the floating switch reaches the start-up level.

## Ch. 5 Maintenance and troubleshooting

In ordinary conditions, FLOTEC VIPVORT series electropumps do not require any maintenance.

It may be necessary to clean the hydraulics or replace the impeller.



DANGER  
Electric shock  
risk

Make sure the machine is disconnected from electric power supply, before performing maintenance operation.

### Hydraulics cleaning VIPVORT (see Fig. 3, Fig. 4, Fig. 5, Fig. 6)

Disassembly of the filter cap: disassemble the filter cap only after removing the safety screw (See Fig. 3, pos. 6). Keep the pump motionless and turn the filter cap clockwise looking at the pump from the bottom. To assemble the filter cap, turn it counterclockwise [see Fig. 4].

If the filter cap is fixed on the base with screws, turn the pump clockwise in the direction of the handle to disassemble it [See Fig. 5].


Disassembly of the diffuser filter VIPVORT

Disassembly of the diffuser filter: disassemble the diffuser filter only after removing the safety screw [See Fig. 3, pos. 5]. Keep the pump motionless and turn the diffuser filter clockwise looking at the pump from the bottom. To reassemble the diffuser filter, lubricate the O-ring with water and turn the filter counterclockwise [see Fig. 6].

Pump storage instructions

Store the pump in a dry place and protect it from frost.

PROBLEM	POSSIBLE CAUSE	REMEDY
1) THE ELECTROPUMP DOES NOT PUMP WATER, THE MOTOR DOES NOT RUN	1) No electricity. 2) Plug inserted incorrectly. 3) Enabled safety switch. 4) Blocked impeller. 5) Damaged motor or condenser.	2) Verify that voltage is present and that the plug is correctly inserted. 3) Reset the safety switch. If the safety switch is once more enabled, contact a specialised electrician. 4) Remove possible obstructions from the impeller. 5) Contact the Customer Assistance Service.
2) THE PUMP DOES NOT SUPPLY WATER BUT THE MOTOR IS RUNNING	1) Obstructed suction grid. 2) Blocked check valve. 3) Air in impeller body (air bubbles).	1) Clean the grid. 2) Clean or replace the valve. 3) Perform several start-ups in order to remove all the air.
3) THE PUMP SUPPLIES A LIMITED AMOUNT OF WATER	1) Partially obstructed suction grid. 2) Obstructed pipe. 3) Worn impeller.	1) Clean the grid. 2) Remove the obstructions 3) Contact the Customer Assistance Service.
4) INTERMITTENT OPERATION	1) Solid particles prevent the free rotation of the impeller. 2) The temperature of the fluid is too high. 3) Voltage out of range. 4) The fluid is too dense. 5) Faulty motor	1) Remove the foreign particles. 3) Supply the pump in accordance with nameplate data. 4) Dilute the pumped fluid. 5) Contact the Customer Assistance Service.



Only for EU countries  
 Do not dispose of electric tools together with household waste material!  
 In observance of European Directive 2002/96/EC on waste electrical and electronic equipment and its implementation in accordance with national law, electric tools that have reached the end of their life must be collected separately and returned to an environmentally compatible recycling facility.